



ARROWHEAD
R O C K D R I L L



R55
Hydraulic Hammer
Parts Manual



ARROWHEAD
ROCK DRILL

R55 PARTS LIST




Diagram Number	Part Number	Description	Quantity
1	1042301	Moil Point	1
2	1042102	Chuck Housing	1
3	1043311	Tool Retainer	1
4	1011104	Grease Nipple	1
5	1011368	Chuck Retaining Bolt Assembly	2
6	1042101	Main Body	1
7	1042104	Piston	1
8	1042105	Upper Cylinder Liner	1
9	1042103	Cylinder Head	1
10	1011367	Cylinder Head Bolt Assembly	8
11	1051201	Valve Housing	1
12	1051202	Valve Bottom Plate	1
13	1051203	Valve Top Plate	1
14	1051204	Valve Spool	1
15	1051205	Plunger	1
16	1011202	Valve Plate Bolts	8
17	1011201	Pressure Plug	1
18	1011113	Gas Valve Adaptor	1
19	1011105	Gas Valve Assembly	1
20	1011122	Dowel Pins	2
21	1042401	Seal Kit	1
22	1011214	Valve Housing Plug	2
23	1011304	Hose Adaptors	2
24	1011204	Valve to Body Bolts	10
25	1011102	Inspection Port Plug	1
26	1042302	Chisel	1
27	1042303	Blunt	1
28	1042304	1 Piece Post Driver	1
29	1042305	2 Piece Post Driver	1
30	1042306	Tarmac Cutter	1
31	1042307	Power Fist	1
32	1011302	Tool Retaining Rubber Doughnut	1
33	1042309	Hammer Box	1
34	1042313	Decal Set	1
35	1042310	Lower Buffer	1
36	1042315	Upper Buffer	1
37	1022312	Top Bracket	1
38	1011366	Top Bracket Bolt Assembly	6
39	1011321	Pressure Hose (Europe)	2
40	1011329	Pressure Hose (Americas)	2
41	1011112	Gas Valve Spring	1
42	1011111	Gas Valve Shuttle	1
43	1011110	Gas Valve Small O Ring	1
44	1011108	Gas Valve Large O Ring	1
45	1011109	Gas Valve Dowty Washer	2
46	1011107	Gas Valve Body	1
47	1011106	Gas Valve Dust Cap	1



ARROWHEAD R55 POWERCELL BREAKDOWN




ARROWHEAD
ROCKDRILL



ARROWHEAD R55 HAMMER BREAKDOWN



ARROWHEAD
ROCKDRILL



GAS VALVE ASSEMBLY PARTS BREAKDOWN